



# Viridian Systems Limited

## Installation

In normal operation the pump is installed in a dedicated leachate well, sump or landfill gas condensate vessel as shown in the illustration below: -

